

auger drives

EMD
15
20



IMPORTANT!

Variable Speed Models - EMD-20 Only.
Variable speed motor **MUST NOT BE OPERATED**
without being pre-filled with hydraulic fluid. Operating
the motor without hydraulic fluid **WILL CAUSE**
EXTENSIVE DAMAGE.

The motor has been equipped with quick connect
couplers to ensure the motor has fluid at all times.
The motor is filled with hydraulic fluid at the factory
and is shipped in a ready to use condition.

All DV series units require the use of a motor case
drain line. **THE DRAIN LINE MUST BE USED TO**
AVOID DAMAGE TO THE HYDRAULIC MOTOR.



excavator mounted drill

owners manual
operators instructions
spare parts list
safety precautions
maintenance

DAWSON CONSTRUCTION PLANT LTD.
CHESNEY WOLD,
BLEAK HALL
MILTON KEYNES
MK6 1NE, ENGLAND
TEL: +44 (0) 1908 240300
FAX: +44 (0) 1908 240222
EMAIL: JON@DCPUK.COM
WWW.DCPUK.COM



preface

This manual is used to familiarise you with safety, assembly, operation, adjustment, troubleshooting, and maintenance. Read and follow the recommendations in this manual to ensure safe and efficient operation. Keep this manual with the attachment at all times for future reference.

We want you to be completely satisfied with your new product, feel free to contact your local authorized service dealer for help with service, replacement parts, or any other information you may require. If you need assistance in locating a dealer, visit our web site at www.dcpuk.com or call customer service at +44 (0) 1908 240300.

Whenever you contact your authorised service dealer, always have the model number and serial number of your product available. These numbers will help provide exact information about your specific product. You will find the model and serial numbers on an ID plate located on the product.

The descriptions and specifications in this manual are subject to change without notice. Dawson reserves the right to improve products. Some product improvements may have taken place after this manual was printed.

table of contents

Preface / Table of Contents	2
EU Declaration of Conformity	4
Safety Statements	6
General Precautions	7
General Precautions Continued	8
Product Equipment Precautions / Serial Number Identification	9
Safety Sticker Information	10
Product Specifications	11
Typical Attachment Connections	12
Extractor Operating Positions	13
Extractor Operating Positions Cont.	14
Set-Up Instructions / Hydraulic System Hook-Up	15
Operating Procedures	16
Maintenance Instructions	17
Operating Procedures/ Storage Instructions	18
Checking and Changing Gear Oil	19
EMD15 Two Speed Hydraulic Motor Info / Auto Shift Principal	20
EMD15 Two Speed Hydraulic Motor Info	21
EMD15 Two Speed Hydraulic Motor Repair Info Cont'd	22
Troubleshooting	23
EMD 20 Hydraulic Motor Quick Coupler Connection	24
EMD 20 Variable Speed Hydraulic Motor Information	25
EMD 15 Parts Breakdown- Dawson 610800	26
EMD 15 Gearbox (610357) Parts List	27
EMD20 Parts Breakdown- Dawson 610814	28
EMD 20 Gearbox (610357) Parts List	29
Warranty Policy/ Returned Goods Policy	30
Torque Chart for Common Bolt Sizes	31



Certificate

Declaration of Conformity

We declare that the machinery/equipment detailed below is in compliance with the applicable regulations and harmonised standards as listed. This declaration ceases to be valid if alterations are made the machinery/equipment without agreement with Dawson Construction Plant Ltd.

Category	Piling Equipment
Type	EMD
Serial Number	220- 042
Year of Manufacture	2016
Power kW	42
Suitable Excavator Range	7-18 tonnes

Relevant Regulations:

2006/42/EC	Machinery Directive
2000/14/EC	Noise emission in the environment -

Applied harmonised standards, in particular:

EN 12100-1:2010	Safety of machinery. Basic terminology and methodology
EN 16228-1:2014	Drilling & foundation equipment. Common requirements
EN 16228-4:2014	Drilling & foundation equipment. Foundation Equipment
EN 16228-7:2014	Drilling & foundation equipment. Interchangeable auxiliary equipment

Signed by on behalf of DCP


Name / Position

DAVID BROWN - MANAGING DIRECTOR

Date


/ /


safety statements


DANGER  THIS STATEMENT IS USED WHERE SERIOUS INJURY OR DEATH WILL RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.


WARNING  THIS STATEMENT IS USED WHERE SERIOUS INJURY OR DEATH COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.


CAUTION  THIS STATEMENT IS USED WHERE MINOR INJURY COULD RESULT IF THE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.

 THIS SYMBOL BY ITSELF OR USED WITH A SAFETY SIGNAL WORD THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY OR THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.

WARNING  **READ MANUAL PRIOR TO INSTALL**
Improper installation, operation, or maintenance of the equipment could result in serious injury or death. Operators and maintenance personnel should read this manual as well as all manuals related to this equipment. FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL.

WARNING  **READ AND UNDERSTAND ALL SAFETY STATEMENTS**
Read all safety stickers and safety statements in all manuals prior to operating or working on this equipment. Know and obey all regulations, local laws and other professional guidelines for your operation. Know and follow good work practices when assembling, maintaining, repairing, mounting, removing or operating this equipment.

 **KNOW YOUR EQUIPMENT**
Know your equipment's capabilities, dimensions and operations before operating. Visually inspect your equipment before you start, and never operate equipment that is not in proper working order with all safety devices intact. Check all hardware to assure it is tight. Make certain that all locking pins, latches, and connection devices are properly installed and secured. Remove and replace any damaged, fatigued or excessively worn parts. Make certain all safety stickers are in place and are legible. Keep stickers clean, and replace them if they become worn and hard to read.

WARNING  **DO NOT MODIFY EQUIPMENT**
Modifications may weaken the integrity of the equipment and may impair the functions, safety, life, and performance of the equipment. When making repairs, use only the manufactures genuine parts, following authorised instructions. Other parts may be substandard in fit and quality.

 **PREPARE FOR EMERGENCIES**

- Be prepared if a fire starts.
- Keep a first aid kit near by when operating equipment.

general precautions

WARNING



OPERATOR SAFETY

- Protective clothing and equipment should be worn at all times.
- Wear protective clothing and equipment appropriate for the job. Avoid loose fitting clothing.
- Prolonged exposure to excessive noise can cause hearing loss.
- Operating equipment safely requires the full attention of the operator. Avoid distractions.
- Do not operate the unit when you are tired, ill or under the influence of alcohol, drugs or medication.
- Never let a minor or inexperienced person operate the unit.
- Keep all body parts away from the drilling bit at all times.
- Inspect the area to be drilled before operation. Remove objects which can be thrown or become entangled.
- DO NOT operate the Drive attachment in areas where carbon monoxide fumes can accumulate.

CAUTION



PRODUCT SAFETY

- Inspect the entire product before operation.
- Replace parts that are cracked, chipped or damaged in any way before operation.
- Keep others away when making any adjustments to the unit.
- Damage to the Auger Drive and auger bit can result if the excavator moves while the auger is still in the hole.

WARNING



PRACTICE SAFE MAINTENANCE

- Use proper tools and equipment when conducting maintenance.
- Work in a clean dry area.
- Inspect all parts. Be sure parts are in good working condition and installed properly.
- Remove build up of grease, oil or any debris.
- Remove all tools and unused parts from equipment before beginning operation.

WARNING



BE ALERT ON THE JOB SITE

Tragic accidents can occur if the operator is not alert to the presence of bystanders.

WARNING



DRILLING SAFETY

- Inspect the area to be drilled before operation. Remove objects which can be thrown or become entangled. Be alert when drilling in locations where any type of landscaping fabric / mat may be present. The material can be rapidly drawn into the point of operation, possibly causing injury or death to anyone standing on or near the fabric.
- Keep all parts of your body away from the drilling bit when operating the unit.
- DO NOT operate the Auger Drive when the auger bit is more than 12" (305mm) above ground. The auger bit may bind and cause injury to the operator and damage to the equipment.
- While the auger bit is rotating, DO NOT attempt to manually guide the auger to a location.
- Ensure that overhead power / utility lines do not come into contact with the Drive attachment.
- DO NOT use a shovel or any other object to remove material from the auger bit or the hole while the Drive attachment is in use.

WARNING




UNDERGROUND HAZARDS


It is the responsibility of the operator to know where buried power, gas, telephone, and other utilities are at in the work area. This may lead to shock or an explosion. Ensure correct permits are in place to cover the drilling activity. Striking a hard object underground with the auger turning can result in the slowing or stopping of the auger.

general precautions - continued


WARNING  **LOWER OR SUPPORT RAISED EQUIPMENT**
Do not work under raised booms without supporting them.

WARNING  **USE CARE WITH SILICA DUST DURING OPERATION**
Concrete and masonry products contain silica sand. Quartz, which is a form of silica and the most common mineral in the earth's crust, is associated with many types of rock. Some activities that silica dust may be present in the air include demolition, sweeping, loading, sawing, hammering, drilling, or planing of rock, concrete or masonry.


It is recommended to use dust suppression, dust collection and personal protective equipment during the operation of any attachment that may cause high levels of silica dust.

WARNING  **USE CARE WITH HYDRAULIC FLUID PRESSURE**
Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death. Hydraulic leaks under pressure may not be visible. Before connecting or disconnecting hydraulic hoses, read your excavator's operator's manual for detailed instructions on connecting and disconnecting hydraulic hoses or fittings.

- Keep unprotected body parts, such as face, eyes, and arms as far away as possible from a suspected leak. Flesh injected with hydraulic fluid may develop gangrene or other permanent disabilities.
- If injured by injected fluid, see a doctor at once. If your doctor is not familiar with this type of injury, ask him to research it immediately to determine proper treatment.
- Wear safety glasses, protective clothing, and use a piece of cardboard or wood when searching for hydraulic leaks. **DO NOT USE YOUR HANDS! SEE ILLUSTRATION.**



product / equipment precautions



EXCAVATOR LIFT CAPACITY

Alert yourself to the weight of the Drive Unit. DO NOT exceed the recommended lift capacity of the excavator. Refer to your excavator's owners manual for suggested lift capacity and lift considerations.



EXCAVATOR / ATTACHMENT INSTALLATION

Ensure all connection pins, fasteners and latches are properly secured. Ensure that the mounting frame / attachment mounting plate is rigidly secured to the excavator. Improper installation can result in product damage, personal injury and death.

Ensure all hydraulic hose assemblies are of adequate length and have enough slack for full Drive attachment movement. Failure to provide adequate length hydraulic hoses can result in hose rupturing. A hydraulic hose rupture can result in product damage, personal injury and death.



OPERATING THE EXCAVATOR

Avoid steep hillside operation, which could cause the excavator to overturn. Consult your excavator operator's and safety manuals for maximum incline allowable.



TRANSPORTING THE DRIVE ATTACHMENT

- Travel only with the Drive attachment in a safe transport position to prevent uncontrolled swinging.
- Tether the Drive attachment with a chain, if necessary, to prevent uncontrolled swinging of the auger when moving from hole to hole.
- Remove the earth auger or helical anchor from the Drive attachment before transporting to and from the job site.
- Use extreme care during transport to prevent contact between the Drive attachment and bystanders or solid objects. Contact with the Drive attachment could cause serious damage, injury or death.
- Never operate the Drive attachment while transporting.
- Drive slowly over rough ground and on slopes. Position the Drive attachment as low to the ground as possible maintaining a low center of gravity.



DRIVE ATTACHMENT SIDE LOADING

Side loading is NOT recommended. Excessive side loading can cause output shaft deflection and or failure. Avoid excessive side loading to prevent possible instantaneous output shaft failure. Such a failure could result in injury from disconnected parts and or being hit by the Drive attachment causing serious injury or death.

serial number identification



Its important to make the correct reference to the serial number of the unit when making repairs or ordering parts. The serial number plate will be located near the top of the Anchor / Auger Drive attachment.

Figure.1

safety stickers information



SAFETY STICKERS

This unit comes equipped with all safety stickers in place. They are designed to help you safely operate your unit. Read and follow all safety stickers.

- Keep all safety stickers clean and legible at all times.
- Replace safety stickers that are missing or have become illegible.
- Safety stickers are available from your distributor or manufacture.
- Some parts installed during repair may require safety stickers to be affixed to the replacement part.

When ordering the replacement part(s) be sure the correct safety stickers are included in your order.



INSTALLING SAFETY STICKERS

- Clean the desired area with warm soapy water.
- Decide on exact position before you remove the backing paper.
- Peel backing paper from stickers. Press firmly on the surface.
- Air pockets can be pierced with a pin and smoothed.

Typical stickers used on Auger Drive Attachments



Figure.2

product specifications

AUGER DRIVE MODEL

EMD-15

TOTAL UNIT WEIGHT	825 LBS / 374 Kg
HYDRAULIC MOTOR INFORMATION	
Displacement	17.8 cu/in (293cc)
Motor Type	Two Speed Bidirectional
Motor Output Shaft	1-1/4" Spline 14T
Motor Mount	SAE - C 4 Bolt
Motor Ports	1-5/8" - 12 UN-2B
Cross Over Pressure Relief	Set @ 3100 psi
PLANETARY GEARBOX INFORMATION	
Gearbox Type	Planetary Two Stage
Reduction Ratio	26.52:1
Output Shaft	3" Hex
Oil Capacity	3.0 Gallons
Oil Type	SAE 80W90 GL-5
Shaft Pull Out (lbs.)	22,500 lbs.
REFERENCE TORQUE CHART	

TWO SPEED MODELS MUST HAVE A MINIMUM OF 75 L (20 GPM) TO OPERATE CORRECTLY.

AUGER DRIVE MODEL

EMD-20

TOTAL UNIT WEIGHT	880 LBS / 400 Kg
HYDRAULIC MOTOR INFORMATION	
Displacement	8.25 cu/in (135cc)
Motor Type	Variable Speed Bidirectional
Motor Output Shaft	8/16 Spline 13T
Motor Mount	SAE - D 2 Bolt
Motor Ports	Radial (Quick Coupler)
Cross Over Pressure Relief	None
PLANETARY GEARBOX INFORMATION	
Gearbox Type	Planetary Three Stage
Reduction Ratio	60.56:1
Output Shaft	3" Hex
Oil Capacity	3.0 Gallons
Oil Type	SAE 80W90 GL-5
Shaft Pull Out (lbs.)	45,000 lbs.
REFERENCE TORQUE CHART	

UNIT REQUIRES A MIN OF 165 Bar (3400 PSI) TO REACH MAX DISPLACEMENT / TORQUE.

DRAIN LINE MUST BE USED TO AVOID DAMAGE TO HYDRAULIC MOTOR.

	EXCAVATOR SIZE	MAX. HOLE DEPTH	MAX. HOLE DIAMETER	WEIGHT	CONNECTIONS (HEX)
EMD-15	11-18 tonne (12-20 ton)	3,658 mm (12')	1,524 mm (5')	375 Kg (825 lbs)	3"
EMD-20	11-18 tonne (12-20 ton)	6,096 mm (20')	1829 mm (6')	400 Kg (880 lbs)	3"

Output speed and torque specifications are NOT listed at 100% efficiency. Maximum efficiencies have been applied to the torque and speed charts according to the manufacturers recommendations. Speed and torque output are dependant on the overall system efficiencies associated with the excavator hydraulic system. When the purchaser is determining criteria for specific applications please contact Dawson. This document should be used for information and comparative purposed only. When application specific information is required, please contact Dawson. Dawson continually looks for new ways to improve its products. Therefore, Dawson reserves the right to make changes to our products and specifications without notice.

typical attachment connections




IMPORTANT: Before connecting the attachment to excavator, inspect all mounting surfaces, attachment plates, and quick couplers are free of dirt and debris. Ensure all attaching pins, fasteners and latches are properly secured. Ensure that the mounting frame / attachment mounting plate is rigidly secured to the excavator. Improper installation can result in product damage, personal injury and death.

1

EXCAVATOR / BACKHOE MOUNT END OF BOOM (Figure 3)


Mounting Bracket connects directly to the boom with the customer supplier connection pin. The Drive Unit connects to the Mounting Bracket with the supplied connection pin.



2


EXCAVATOR / BACKHOE MOUNT QUICK COUPLER (Figure 4)

Mounting Bracket connects to the quick coupler when the jaws of the quick coupler engage the pins on the Mounting Bracket. The Link Arm connects to both the Mounting Bracket and the Drive Unit with the supplied connection pins.



excavator operating positions


These illustrations represent the recommended working, transport and resting positions for your Dawson Drive attachment when used with an excavator.




A) Recommended: Starting Position
Position the Drive and Auger vertically in desired location and begin drilling.




B) Recommended: Drill
Lower the excavator arms in a consistent vertical manner




C) Recommended: Transport Position
Lift the Auger off the ground during transport on the job site. Keep Auger as low as possible.




D) Recommended: Resting/ Parked
park the excavator with the Auger on the ground.



E) Avoid: Drilling Position
Avoid any drilling position that is not vertical. Auger will be unstable and not easily controlled.



F) Avoid: Drilling Position
Avoid any drilling position that is not vertical. Auger will be unstable and not easily controlled.



G) Avoid: Transport Position
When transporting the Auger on the job site do not allow the Auger to swing in an uncontrolled manner. Damage can occur to the attachment and excavator.

H) Avoid: Resting/ Parked Position
Avoid parking the excavator with the Drive and Auger in a suspended position.


excavator operating positions

These illustrations represent the recommended sequence for positioning the Drive attachment in a resting and or transport position. It is important that the recommendations are followed to prevent damage to the attachment and ensure safety.

Starting Position

Position the Drive and Auger vertically in desired location.

Allow for ample room to maneuver the excavator.




Transition Position

In order to safely position the attachment in a resting position the following steps will need to be completed simultaneously.


1. Lower the excavator boom.
2. Allow the Drive and Auger to rotate towards the ground.
3. Maneuver the excavator in reverse.

During this process the point of the Auger should not lose contact with the ground. Failure to follow this sequence can result in damage. Do not put the Auger in a binding situation, this will cause damage to the Drive output shaft!



Resting Position

When the Drive and Auger are in full contact with the ground the attachment is now in its resting position.



IMPORTANT

Damage to the Drive output shaft can occur if operating instructions are not followed.

set-up instructions

READ AND UNDERSTAND ALL SAFETY INFORMATION PRIOR TO MOUNTING YOUR DRIVE UNIT TO THE EXCAVATOR. SEE PAGES 6 & 10.

MOUNTING AND INSTALLATION

There are several ways to mount your Drive Unit depending on the excavator and application. See figures 3 and 4 on page 12.

Backhoe and Excavator Mounting

Remove the bucket from the dipper arm and curl cylinder pin connections.

AUGER / ANCHOR CONNECTION

1. Align the auger bit or anchor with the output shaft of the Drive Unit.
2. Slide the connecting coupler (hub) over the output shaft and align the coupler hole with the output shaft hole.
3. Connect the auger bit or anchor to the Drive Unit output shaft and secure it with appropriate connecting hardware.

WARNING



When selecting connecting hardware ensure that the bolt or pin does not protrude from the coupler (hub) any more than necessary to secure. Hardware that protrudes an excessive amount can be a safety hazard and cause entanglement

hydraulic system hook-up

Your Planetary Drive Unit receives its hydraulic oil flow and pressure from the excavator through the auxiliary hydraulic circuit via two quick release couplers near the end of the truck boom or excavator arm. Follow the steps below to complete the hydraulic hook-up between your excavator and Drive Unit.

HYDRAULIC SYSTEM HOOK-UP

1. Locate the auxiliary hydraulic connection ports on the excavator.
2. Determine the length of hydraulic hose necessary to connect the auxiliary hydraulic circuit to the Drive Unit. Be sure to allow sufficient “slack” in the hose length to allow the Drive Unit to perform it's full range of operation.
3. Ensure that the hydraulic hose couplers are compatible with the hydraulic quick couplers on the Drive Unit.

WARNING



If a hydraulic leak develops, correct it immediately. Escaping hydraulic fluid can have extremely high pressure. A stream of high pressure fluid may penetrate the skin. It is imperative that the connections are tight and that all hoses are in good working condition.

4. Once all of the hydraulic connections have been made and checked for leaks, the Drive Unit is ready for operation.

CAUTION



Hydraulic hoses and fittings used on the excavator and Drive Unit must have a continuous operating pressure rating of at least 25% higher than the maximum pressure of the hydraulic system being used. Refer to the Drive Unit specification chart for allowable maximum pressure.

operating procedures

Before operating, always ensure that the Drive Unit and auger or anchor are connected correctly to the excavator.

DRILLING / ANCHORING OPERATION

1. To begin drilling/installation, position the auger or anchor on the ground in the desired location. Engage the parent machines auxiliary hydraulics to rotate the auger or anchor in a clockwise direction.
2. Lower the parent machines arm(s) to engage the auger or anchor into the ground. Use only enough down pressure to assure positive penetration. Ease up on the down pressure if the auger or anchor rotation slows down drastically or stalls. Excessive down pressure will cause the Drive Unit to stall frequently.

Note: Do not continually stall the Drive Unit! Continued stalling may cause excessive heating of the hydraulic system and possible damage to the Drive Unit.

3. As the auger or anchor digs in the ground, the excavator arm(s) or boom may travel through an arc. This means the operator may need to continually reposition the auger or anchor to ensure vertical application of the auger or anchor.

DRILLING OPERATION ONLY

After steps 1-3 above have been completed continue with the following steps for drilling applications.

4. When the auger has penetrated the ground about 24" (610mm), raise the auger from the hole to clean out the loose material.
5. Once the required hole depth is reached, allow the auger to turn a few seconds at this depth to clean the hole.
6. Stop rotation of the auger and raise the auger out of the hole. Swing the auger away from the newly drilled hole. Spin the loose material off the auger.

Note: Do not reverse the auger rotation while the auger is still in the hole. The loose material will back fill the hole.

If necessary, repeat steps 4 through 6 to obtain a cleaner hole.

OPERATIONS TO AVOID

1. In some soil conditions or when excessive down pressure is applied, the auger may "screw" itself into the ground. This can cause the auger to become stuck causing the Drive Unit to stall. If this situation occurs, reverse the auger rotation and slowly raise the auger from the hole.
2. If the auger becomes lodged under rocks, tree roots, or other large obstructions, do not attempt to raise the auger out of the ground. See Step 1 of this section to relieve the auger.
3. Avoid excessive side loading. This can cause damage to both the Drive Unit and the auger bit.
4. Keep all auger teeth and pilot bits in good condition. Avoid using damaged teeth and holders.



IMPORTANT: Do NOT over fill grease cavity! Too much grease can compromise the output shaft seal.

Only a small amount grease (.50-1.0 oz) is required every 100 hours of use.

Recommended grease type:

Lithium NLGI 2 Viscosity @ 40 deg C: 220

maintenance instructions

Before operating the Drive Unit ensure it is properly lubricated and inspected for any worn or damaged areas. Only a minimum amount of time and effort is required to regularly lubricate and maintain the Drive Unit. Preventive maintains will help ensure long life and trouble free operation.

LUBRICATION MAINTENANCE

The Drive Unit must be properly lubricated to achieve the most efficient operation. Clean excess grease, gear oil, and hydraulic fluid for the Drive Unit. This is especially important in sandy contions.

HYDRAULIC OIL MAINTENANCE

CLEAN HYDRAULIC OIL IS ESSENTIAL!


80% of all hydraulic component failures are caused by Contamination of the hydraulic oil. Always keep all dirt and other contaminates from entering the hydraulic system during disconnect and connect operations. Always use dust caps and plugs on all quick disconnects when not in use. Tightly cap all hydraulic openings to hold oil in and keep dirt and other contaminates from entering hydraulic systems.

HYDRAULIC HOSE MAINTENANCE

Inspect all hydraulic hoses daily for cracked and brittle covers caused by excessive heat. Reduced viscosity of hydraulic oil occurs at higher operating temperatures and causes a breakdown of fluid additives, such as wear inhibitors. Excessive heat will cause higher internal leakage in the Drive Unit motor, which will make the Drive Unit less efficient. It can also cause seals in the drive unit motor to become brittle and crack. Replacement of hoses before failure will prevent loss of hydraulic oil and down time.

OUTPUT SHAFT LUBRICATION MAINTENANCE

Ensure that the output shaft is properly greased on an as needed basis. The grease fitting for the output shaft is located near the shaft. See location figure below.



operating procedures

GEARBOX MAINTENANCE

The planetary gearbox is filled with gear oil lubricant. If oil is observed leaking, the seal should be inspected for damage or wear and replaced if necessary. Inspect the gearbox for any other possible damage that could be causing the leakage.

Change planetary gear oil after the first 50 hours of operation. Change the gear oil every 1000 hours or 12 months whichever occurs first. CHECK OIL LEVEL DAILY to assure proper lubrication is maintained. See the CHECKING AND CHANGING GEAR OIL section for gear oil grade.

HARDWARE MAINTENANCE

Check Drive Unit and all accessories daily for loose, bent, cracked, or worn bolts and fasteners. Always use Grade 5 or harder replacements bolts. Always use lock washers with standard hex nuts or self locking nuts. Check all connecting pins daily for bends, cracks, breaks, or wear. Replace if any of these conditions exist.

OUTPUT SHAFT MAINTENANCE

Check the Drive Unit output shaft daily for cracks or excessive wear near or around the connection hole. The output shaft should be replaced if any of these conditions exist.

Where replacement parts are necessary for periodic maintenance and servicing, genuine factory replacement parts must be used to restore your unit to original specifications. Manufacturer will not claim responsibility for use of unapproved parts or accessories and other damages as a result of their use.

If equipment has been altered in any way from its original design, manufacturer does not accept any liability for injury or warranty.

storage instructions

When the Drive Unit will not be used for an extended period of time, it should be thoroughly checked and prepared for storage so that a minimum amount of work will be required to put the Drive Unit back into operation. The following are suggestions for storage:

1. Thoroughly clean the Drive Unit.
2. Ensure the hydraulic motor and the hoses are full of clean oil. Be sure the planetary gearbox is full (to the recommended capacity for each model).
3. Tighten all bolts and pins to the recommended torque values.
4. Protect the output shaft with grease or a rust inhibitor.
5. Check the Drive Unit for worn or damaged parts.
6. Store the Drive Unit away from active areas and in a clean dry location.
7. Paint all scratched or bare metal surfaces.

checking / changing gear oil

The Planetary gearbox used on your Drive Unit uses a gear oil to keep the internal gears lubricated. To check and or replace the oil, follow the steps below.

CHECKING THE GEAR OIL:

1. Make sure the Drive Unit is in an upright position when checking the oil.
2. Locate the oil level sight port and visually inspect that oil can be seen. If oil can be seen this is an indication that the oil level is adequate.


CHANGING THE GEAR OIL:

1. Position the Drive unit in a position in which the oil can flow freely from the gearbox once the drain plug is removed.
2. Place a drain pan under the drain port.
3. Remove the drain plug and allow the oil to completely drain out. Allow 10-15 minutes for oil to drain completely.
4. Position the gearbox for filling by orientating the unit so that the oil fill port is accessible. In most cases the bail housing will need to be removed to access the oil fill port, which is located in the top section of the gearbox, near the motor.
5. Replace oil drain port and fill the gearbox with the required amount of gear oil. **For the correct capacity of gear oil refer to the model specification page.** The gear oil specifications is listed below:

Lubrication Recommendations:

SAE 80W90 GL-5 Oil
Density / 15 deg C: 0.895
Viscosity Index: 97
Viscosity @ 40 deg C: 138
Flash Point COC: 200
Viscosity @ 100 deg C: 13.9
Pour Point (deg C): -30

The Bail Housing will need to be partially removed to allow access to all ports during oil change.



Oil Fill Port



Oil Level Sight Port


Oil Drain Port



IMPORTANT

DO NOT overfill gearbox when replacing the gear oil. Excessive amount of gear oil will reduce the amount of room in the gearbox for expansion and cause damage to the seals.

emd15 2 speed hydraulic motor information



auto shift principal

On the "Auto Shift" models the motor is equipped with an automatic kick down sequence valve, adjustable between the range of 27 and 206 Bar respectively. The Unit will start in high speed low torque mode until the preset pressure is reached upon where it will automatically shift into low speed high torque mode. The unit will shift automatically back to high speed mode when input flow is stopped. **Two speed Auger Drives (EMD-15 Series) DO NOT require a return-drain line.**

CROSS-OVER PRESSURE RELIEF SYSTEM

Note all two speed motors are equipped with a cross-over pressure relief system. This system is designed to protect the hydraulic motor from pressure spikes and potential overload conditions associated with hydraulically powered equipment. The cross-over relief setting is factory set at 213 Bar and is not adjustable.

emd15

2 speed hydraulic motor information

SMDH MOTOR SEAL REPLACEMENT PROCEDURE

1. With the mounting flange removed from the unit, lay the flange on a clean surface with the pilot face down. Using a 1/4" punch or flat head screwdriver with a bent tip, insert this tool through the drive bearing and past the inner seal to the outer metal edge of the outer seal case. Tap around the seal repeatedly to push the seal out of the bore. **Do not score or scratch the seal bore or the bearing.**
2. Turn the flange over and remove the snap ring with snap ring pliers.
3. The old steel back up washer and high pressure seal should be removed by hand (little or no force required).
4. Clean the seal bore and drive bearing thoroughly with solvent and inspect for scratches, nicks, or burrs. Scratches on the seal bore will lead to leaks around the outer edge of the seal. Scratches or burrs on the bearing will lead to bearing failure.
5. Refer to figure 6A for inner high pressure seal. The "spring side" of the seal will face toward the bearing.
6. Coat the OD of the 625256 seal with Loctite 609. Using a socket with an OD slightly smaller than the seal bore ID (1.996 in. min) press the seal into the bore with the lip with garter spring facing towards the bearing with a hydraulic or arbor press. The seal must be kept square with the bore while pushing (pusher must not be cocked). The seal should bottom out against the snap ring.
7. Install new 626698 rubber plug into 3/16" "weep hole" on side of flange if old one is missing.
8. Remove old 66-156-19359 O-Ring from flange and install new O-Ring into groove. Using grease on the O-Ring helps keep it seated during flange reassembly.
9. Use a generous amount of grease on spline drive shaft to avoid cutting seals and replace flange onto unit.
10. Replace washers and nuts and torque in a criss-cross pattern to 80-90 ft-lbs.



NOTE: The general work area and all parts must be clean and free of dust and dirt that could contaminate the seal areas on the seal lips or shaft.

MATERIALS REQUIRED FOR SEAL REPLACEMENT:

- 1/4" punch or flat head screwdriver with tip bent
- Socket which OD is slightly smaller than flange seal bore (seal bore ID is 1.996 in. min.)
- Snap ring pliers
- Mineral spirits or equivalent cleaning solvent
- Loctite® 609 or equivalent
- Heavy grease
- Seal Kit part number 661003

661003- SEAL KIT CONTAINS			
ITEM	PART No.	QTY	DESCRIPTION
1	55-906-02-8309	2	O-RING
2	55-906-04-8309	1	O-RING
3	625133	8	BACK-UP RING
4	625256	1	SEAL 1-1/4" VITON - GREEN
5	626698	1	PLUG NEOPRENE - WEEP
6	633199	8	SEAL STRIP
7	66-028-19359	8	O-RING VITON
8	66-156-19359	1	O-RING VITON - FLANGE
9	66-158-19359	3	O-RING VITON
10	66-159-19359	1	O-RING VITON
11	66-906-06-N552-90	9	O-RING BOSS
12	66-906-20-8309	2	O-RING BOSS
13	66-906-3-8309	2	O-RING BOSS
14	69-5000-200	1	SNAP RING
15	721777	1	WASHER B/U 1-1/4" ID
16	721801	1	SEAL 1-1/4" MD HIGH PSI
17	722978	1	VENT PLUG
18	73-187-03752	1	SPRING PIN 3/16"D X 3/8"L

MOTOR REPLACEMENT SEAL / O-RING PARTS

Replacement seals and o-rings are sold in one kit as listed above. The kit is intended to provide quick and complete replacement. Please note seal kit will not be broken apart to supply an individual item within the kit, the entire kit must be purchased.




Figure 8

troubleshooting

In the event your Drive Unit malfunctions or does not appear to have enough speed or power, please refer to the section below to identify the cause of the problem and possible remedy. If the problem persists, contact your Authorized Service Dealer for assistance.

SLOW SPEED (RPM) OR INSUFFICIENT DIGGING POWER:

- Low oil flow / Obstructed oil flow. Check excavator pump. Check for faulty pressure relief valve.
- Auger Drive is too large for machine. Review Drive Unit specs. Contact your Authorized Service Dealer.
- Check auger and teeth for excessive wear. Replace worn auger components.

NO OUTPUT ROTATION:

- Quick release couplers not engaged. Check coupler connection.
- Quick release coupler faulty. Replace faulty coupler(s).
- Hydraulic oil tank is low. Fill oil tank to maximum level.
- Planetary gear failure. Contact your Authorized Service Dealer.
- Machine oil pump failure. Refer to excavator manual.
- Insufficient oil flow. All two speed models require a min of 20 GPM to operate.

BAIL HOUSING LEAKING OIL:

- Hose(s) of Fitting(s) leaking. Tighten or replace.
- Motor O-ring failure. Replace damaged O-ring.

OUTPUT SHAFT LEAKING OIL:

- Output shaft seal damaged. Replace seal.
- Seal not sealing in the housing. Replace seal or use a sealant on OD of seal.
- Bolts are loose. Tighten Bolts.

AUGER / ANCHOR BIT WILL NOT ENGAGE OR DIG:

- Auger bit is worn or damaged. Replace cutting head or entire auger bit.
- Drive Unit speed is too fast. Reduce speed (rpm) to allow bit to engage ground.
- Anchor not installing vertically. Level Drive unit. Allow Drive unit to hang freely.


NO TORQUE:

- Oil pressure is too low. Review Drive unit pressure requirements.
- Drive unit too small for parent machine. Review Drive Unit specs. Contact your Authorized Service Dealer.
- Hydraulic system is overheating. See the "Oil Overheating" section below.

HYDRAULIC OIL OVERHEATING:

- Oil pressure is too low. Set relief valve to machine specifications.
- Hydraulic line is restricted. Inspect and repair.
- Auger continually stalling. Limit down pressure used.
- Hydraulic oil tank is low. Fill oil tank to maximum level.
- Oil passing over relief valve. Check for a faulty relief valve.
- Excavator is too small. Attach Drive Unit to larger excavator.
- Dirty or contaminated oil. Replace excavator hydraulic oil and oil filters.

hydraulic motor quick coupler connection



Motor Quick Coupler Connection

The DV series Auger Drives use a threaded quick coupler on the hydraulic motor. The DV series hydraulic motor must maintain fluid in the motor at all times. These quick couplers ensure that the motor will always maintain a minimum level of fluid. These quick couplers also make connecting to the auxiliary hydraulic circuit easier when residual pressure is present in the line.

These quick couplers should not be replaced by another coupler that does not allow fluid to remain in the motor. Replacing these couplers with a method that does not retain fluid in the motor can lead to damage and will not be covered by warranty.


Use the illustration below to ensure the threaded quick couplers are connected properly before beginning operation.



CAUTION


IMPROPER CONNECTION HAZARD:

To ensure proper coupling, female sleeve and male nipple **MUST HAVE METAL TO METAL CONTACT**. O-ring partially exposed indicates improper coupling.



CORRECT CONNECTION

Metal to metal contact.



INCORRECT CONNECTION

O-ring is exposed.
Do NOT use in this condition.

emd20 motor information

variable speed hydraulic motor information

DV-20 MOTOR
Part No: 610355

These fittings are provided with the Drive. Use these fitting to complete the hoses used on the excavator.
(Item numbers 2, 3 and 9)




Figure 9

MOTOR SEAL INFORMATION

COMPLETE SEAL KIT P/N	SHAFT SEAL ONLY P/N
610705	661400

DV-20 FITTING / HOSE KIT (610369)

ITEM	PART No.	QTY	DESCRIPTION
1	610371	1	FITTING QCK CONN CD62
2	610363	1	FITTING QCK CONN VEP COUPLER
3	610364	1	FITTING QCK CONN VEP NIPPLE
4	610365	2	SPLIT FLG ASSY CODE 62 1" PORT
5	610366	1	HOSE ASSY CASE DRAIN DV-20
6	610367	1	FITTING NJ-MM 7005-12-L18-26
7	610368	1	FITTING MJ-MAORB 90 DEG
8	660825	1	FITTING QCK CONN 3/4" MALE FF
9	660824	1	FITTING QCK CONN 3/4" FEMALE FF
10	610370	1	FITTING QCK CONN VEP 17HD CD62




Figure 10



IMPORTANT

Variable speed motor **MUST NOT BE OPERATED** without being pre-filled with hydraulic fluid. Operating the motor without hydraulic fluid **WILL CAUSE EXTENSIVE DAMAGE**.

The motor has been equipped with quick connect couplers to ensure the motor has fluid at all times. The motor is filled with hydraulic fluid at the factory and is shipped in a ready to use condition.

All DV series units require the use of a motor case drain line. **THE DRAIN LINE MUST BE USED TO AVOID DAMAGE TO THE HYDRAULIC MOTOR.**

emd15 parts breakdown- dawson 610800




Figure 11

ITEM	PART No.	QTY	DESCRIPTION
1	610151	15	SCREW HEX SOC HD M16 X 160
2	610801	1	BAIL PAINTED DT-15 DAWSON
3	700760	15	WASHER LOCK 16mm
4	135501	2	DECAL CAUTION 3000 PSI
5	350291	1	DECAL MOTOR PORTS RT SERIES
6	610169	1	SERIAL TAG
7*	350247	1	DECAL DANGER AUGER DRIVE
8	610005	1	GEARBOX RE2522 26.52:1
9	137363	4	STUD THREADED M12 X 50
10	660739	1	GASKET SAE-C
11	610181	1	MOTOR HYD SMDH 4545 XPR
12	700535	4	WASHER LOCK 12mm
13	174508	4	NUT HEX M12

* Indicates item not shown




Figure 12

Please order replacement parts by PART NO. and DESCRIPTION.

emd15 gearbox (610357) parts list




Figure 13

ITEM	PART No.	QTY	DESCRIPTION
1	610244	1	SUPPORT RE2520
2	610245	1	GEARSET RE2520 5.20
3	610246	1	INTERMEDIATE FLANGE RE2520
4	610247	1	GEARSET RE810 5.10
5	610248	1	INPUT SUPPORT RE810 / RE1020
6	610249	1	MOTOR INPUT
7		12	SCREW M12
*	610274	1	SEAL KIT

GEARBOX REPLACEMENT PARTS

Replacement parts for the gearbox are sold in modules as indicated by the exploded view drawing. These modules are intended to provide quick and complete replacement. Each module will include all the parts necessary to complete the section, this include seals and o-rings. The seal kit which includes all seals and o-rings can be purchased separately.

Please note modules will not be broken apart to supply an individual item within the module, the entire module must be purchased.

WARRANTY NOTICE:

Any attempt to disassemble or make field repairs to the planetary gearbox will VOID the warranty. Please contact your dealer or distributor for further information.

Please order replacement parts by PART NO. and DESCRIPTION.

emd20 parts breakdown- dawson 610814




Figure 14

ITEM	PART No.	QTY	DESCRIPTION
1	610151	15	SCREW HEX SOC HD M16 X 160
2	610811	1	BAIL PAINTED DV-20 DAWSON
3	700760	15	WASHER LOCK M16
4	610369	1	HOSE KIT RV-20
5	610169	1	SERIAL TAG
6	*350247	1	DECAL DANGER
7	610357	1	GEARBOX RE2523 60.52:1 DV-20
8	610360	1	GASKET DV-20
9	610355	1	MOTOR HMR-135 DV-20
10	610095	2	WASHER LOCK 20mm
11	610094	2	SCREW HEX SOC M20 X 65mm

* Indicates item not shown




Figure 15

Please order replacement parts by PART NO. and DESCRIPTION.

emd20 gearbox (610357) parts list




Figure 16

ITEM	PART No.	QTY	DESCRIPTION
1	610244	1	OUTPUT SUPPORT
2	610283	1	GEARSET RE2520
3	610246	1	INTERMEDIATE FLANGE RE2520
4	610284	1	GEARSET RE1020 3.56
5	610164	1	INPUT SUPPORT 810 / 1020
6	610285	1	GEARSET RE310 4.25
7	610160	1	INPUT SUPPORT RE310 / 510
8	610356	1	MOTOR INPUT DV-20
*	610275	1	SEAL KIT

* Indicates item not shown

GEARBOX REPLACEMENT PARTS

Replacement parts for the gearbox are sold in modules as indicated by the exploded view drawing. These modules are intended to provide quick and complete replacement. Each module will include all the parts necessary to complete the section, this include seals and o-rings. The seal kit which includes all seals and o-rings can be purchased separately.

Please note modules will not be broken apart to supply an individual item within the module, the entire module must be purchased.

WARRANTY NOTICE:

Any attempt to disassemble or make field repairs to the planetary gearbox will VOID the warranty. Please contact your dealer or distributor for further information.

Please order replacement parts by PART NO. and DESCRIPTION.

warranty policy

LIMITED WARRANTY

Dawson Construction Plant Ltd. (DCP), warrants its products against faulty design, material, and workmanship for the periods listed below. The warranty starts on the delivery date to the retail owner and is non-transferable.

WARRANTY PERIOD (Dating from the delivery to the original user)

Gearbox: 24 months or 500 operational hours, whichever occurs first.

Hyd. Motor: 12 months or 250 operational hours, whichever occurs first.

WARRANTY SERVICE

All new DCP products are warranted to be free from defects in material and workmanship, which may cause failure under normal usage and service when used for the purpose intended. The DCP warranty covers faulty workmanship and defective parts manufactured by DCP. The warranty does not extend to transportation cost of parts nor does it cover consequential loss, damage to Hydraulic Hoses or ground engaging parts such as Sprockets, Digging Chain, Bearings and Teeth.

DCP Equipment must be operated in accordance with the recommended procedures and within the ranges as specified both on the Unit and contained in the Operating Manual.

Any claims under this warranty must be made within fourteen (14) days after the buyer learns of the facts upon which claim is based. All claims not made in writing and not received by DCP within the time specified above may be deemed waived. DCP will not be responsible for or accept any charges for work carried out by any repairs, or for any charges for any spare parts fitted to any DCP products without written approval from DCP. DCP's liability for any and all losses and damages to buyer resulting from any cause whatsoever, including DCP negligence irrespective of whether such defects are discoverable or latent, shall in no event exceed the purchase price of the particular parts, with respect to which losses or damages are claimed, or, at the discretion of DCP the repair or replacement of defective or damaged parts.

VOID WARRANTY

This warranty is void if field repairs or modifications have been made to the motor, gearbox and or controls without written approval. The complete unit must be available for inspection in it's original but alleged failed condition. This warranty does not apply to normal wear or to damage resulting from accident, abnormal use, abuse or neglect.

PRODUCT IMPROVEMENTS

Product improvement and modifications is an on going process at DCP. DCP reserves the right to make changes or additions to any product or to the warranty without incurring any obligations to make such changes available for previously sold products.

DCP makes no other warranty. All other warranties, whether expressed or implied, such as warranties of merchantability or fitness for a particular purpose, are hereby excluded and disclaimed to the extent that they exceed the warranties expressly granted in this limited warranty. In no event shall DCP be liable for consequential or incidental damages.

returned goods policy







DCP reserves the right to determine whether products claimed to be defective shall be inspected by our personnel in the field or returned to the factory. If judged by DCP to be defective in material or workmanship, the product will be replaced or a credit issued at the option of DCP.

Upon notification of defect, DCP's Inside Sales Department will issue a Return Materials Authorization (RMA) number. All returns for replacement or credit MUST be accompanied by a RMA number. **Products returned without an RMA number will be rejected and returned to the sender freight collect.** All returns must be shipped "prepaid". Products shipped "collect" will be refused. Proof of purchase such as invoice number must accompany returns.

All RMA's must be returned within 30 days of the request.

torque chart for common bolt sizes

The chart below lists the correct tightening torque for fasteners. When bolts are to be tightened or replaced, refer to this chart to determine the grade of the bolt and the proper torque. Except when specific torque values are list in a particular application.

													
Bolt Size (In)	Grade 2		Grade 5		Grade 8		Bolt Size (mm)	Class 5.8		Class 8.8		Class 10.9	
tpi	Nm	Ft-Lbs	Nm	Ft-Lbs	Nm	Ft-Lbs	mm x	Nm	Ft-Lbs	Nm	Ft-Lbs	Nm	Ft-Lbs
1/4"-20	7.4	5.6	11	8	16	12	M5 X 0.8	4	3	6	5	9	7
1/4"-28	8.5	6	13	10	18	14	M6 X 1	7	5	11	8	15	11
5/16"-18	15	11	24	17	33	25	M8 X 1.25	17	12	26	19	36	27
5/16"-24	17	13	26	19	37	27	M8 X 1	18	13	28	21	39	29
3/8"-16	27	20	42	31	59	44	M10 X 1.5	33	24	52	39	72	53
3/8"-24	31	22	47	35	67	49	M10 X 0.75	39	29	61	45	85	62
7/16"-14	43	32	67	49	95	70	M12 X 1.75	58	42	91	67	125	93
7/16"-20	49	36	75	55	105	78	M12 X 1.5	60	44	95	70	130	97
1/2"-13	66	49	105	76	145	105	M12 X 1	90	66	105	77	145	105
1/2"-20	75	55	115	85	165	120	M14 X 2	92	68	145	105	200	150
9/16"-12	95	70	150	110	210	155	M14 X 1.5	99	73	155	115	215	160
9/16"-18	105	79	165	120	235	170	M16 X 2	145	105	225	165	315	230
5/8"-11	130	97	205	150	285	210	M16 X 1.5	155	115	240	180	335	245
5/8"-18	150	110	230	170	325	240	M18 X 2.5	195	145	310	230	405	300
3/4"-10	235	170	360	265	510	375	M18 X 1.5	220	165	350	260	485	355
3/4"-16	260	190	405	295	570	420	M20 X 2.5	280	205	440	325	610	450
7/8"-9	225	165	585	430	820	605	M20 X 1.5	310	230	650	480	900	665
7/8"-14	250	185	640	475	905	670	M24 X 3	480	355	760	560	1050	780
1"-8	340	250	875	645	1230	910	M24 X 2	525	390	830	610	1150	845
1"-12	370	275	955	705	1350	995	M30 X 3.5	960	705	1510	1120	2100	1550
1-1/8"-7	480	355	1080	795	1750	1290	M30 X 2	1060	785	1680	1240	2320	1710
1-1/8"-12	540	395	1210	890	1960	1440	M36 X 3.5	1730	1270	2650	1950	3660	2700
1-1/4"-7	680	500	1520	1120	2460	1820	M36 X 2	1880	1380	2960	2190	4100	3220
1-1/4"-12	750	555	1680	1240	2730	2010							
1-3/8"-6	890	655	1990	1470	3230	2380							
1-3/8"-12	1010	745	2270	1670	3680	2710							
1-1/2"-6	1180	870	2640	1950	4290	3160							
1-1/2"-12	1330	980	2970	2190	4820	3560							

tpi = Nominal thread diameter in inches per inch.

Nm = Newton Meters.

Ft-Lbs = Foot Pounds

mm x = Nominal thread diameter in millimeters x thread pitch.



D.C.P. RESERVES THE RIGHT TO DISCONTINUE EQUIPMENT AT ANY TIME, OR CHANGE SPECIFICATIONS OR DESIGNS WITHOUT NOTICE OR INCURRING OBLIGATIONS

INNOVATION PILING EQUIPMENT

HYDRAULIC PILING HAMMERS

EXCAVATOR MOUNTED VIBRATORS

EXCAVATOR MOUNTED DRILLS

QUIET, VIBRATIONLESS PUSH-PULL PILING

PILE EXTRACTION

SHEET PILE GUIDE FRAMES

SHEET PILE CAPPING SYSTEMS

CFA CLEANERS

PILE POINTS & SPLICERS

SAFETY HANDLING / LIFTING EQUIPMENT

SHEET PILE THREADERS

excavator mounted drill

emd15

emd20

DAWSON CONSTRUCTION PLANT LTD.
CHESNEY WOLD,
BLEAK HALL
MILTON KEYNES
MK6 1NE, ENGLAND
TEL: +44 (0) 1908 240300
FAX: +44 (0) 1908 240222
EMAIL: JON@DCPUK.COM
WWW.DCPUK.COM

